



LONG REACH COMFORT WIPER

INSTRUCTION MANUAL



[Scan QR Code for Video Guide](#)

Personal care tasks can become difficult when bending, twisting, or reaching causes pain or strain. This self assist toilet aid is designed to support independence with toileting by extending your reach and reducing the physical effort required.

The wand allows you to securely hold toilet paper at the tip, clean effectively, and then release the paper directly into the toilet using the built in release mechanism. There is no need to touch the paper after use. Once finished, the aid can be easily cleaned with soap and water or wipes, ready for next time.

Lightweight and compact, it can be kept discreetly in the bathroom or carried in a bag when out and about. Made from durable plastic and silicone, it can be used dry or wet and supports different levels of clean up.

A practical, dignity preserving tool that helps make everyday personal care more manageable.

Great for:

- Reduced reach or flexibility
- Back, hip, or abdominal pain
- Muscle weakness or limited strength
- Pregnancy and post birth recovery
- Disabilities that affect mobility or dexterity
- Older adults wanting to maintain independence
- Anyone who finds bending or twisting difficult



LONG REACH COMFORT WIPER

INSTRUCTION MANUAL

Features:

- Extended reach for easier wiping
- Easy release button for hygienic disposal
- Can be used dry or wet
- Lightweight and portable
- Easy to clean between uses
- Includes wall storage options

Image Description: A long handled self assist toilet aid with a curved ergonomic handle and a soft silicone grip head. Images show toilet paper wrapped around the tip, the release mechanism in use, and wall storage accessories including an adhesive mount and hook.

Details:

Material: Plastic, Silicone

Size: 40cm (L) x 4cm (diameter) x 4.5cm (widest)

Wall Adhesive: 7cm (W) x 7cm (L)

Metal Hook: 7.5cm (L) x 3.5cm (W) x 1cm (D)

Weight: 160 grams Approx.

Package includes: 1x Self-Assist Toilet Aid

Age Guidance: Suitable for teens and adults. Not a toy. Intended for personal care support only.

How to Use:

1. Wrap toilet paper around the tip and secure into the grip
2. Clean as needed
3. Press the release button to drop paper into the toilet
4. Clean the aid after use

Care Instructions:

- Wash with warm soapy water or wipes
- Rinse and allow to dry
- Do not place in dishwasher